

Noise 7

Multiple Choice Quiz

TI Precision Labs – Op Amps



Quiz: Noise 7

1. (T/F) A 10x scope probe is better than a 1x scope probe for noise measurements.
 - a. True
 - b. False

2. (T/F) The bandwidth limiting feature can be used to improve the noise floor.
 - a. True
 - b. False

3. Which of the following is NOT a recommended procedure for measuring 1/f noise?
 - a. Set scope in ac coupling mode
 - b. Use a 0.001Hz high pass filter.
 - c. Set time scale to 1 sec per division.

4. (T/F) Ac coupling should be used for broadband noise measurements.
 - a. True
 - b. False

Quiz: Noise 7

5. What advantage does a spectrum analyzer have over an oscilloscope in noise measurements?

- a. Operation of the spectrum analyzer is fast and simple.
- b. The spectrum analyzer is more accurate
- c. The spectrum analyzer makes it easy to see if you have high frequency content at a specific frequency.
- d. The spectrum analyzer can operate to low frequencies.

6. Which is NOT an important precaution for noise measurements?

- a. Use shield cables to connect to the circuit under test.
- b. Use low ESR capacitors for coupling the circuit under test to the test equipment.
- c. Use linear power supplies or batteries.
- d. Test the noise floor of your equipment.

7. (T/F) The maximum frequency that a spectrum analyzer can measure is called its measurement bandwidth.

- a. True
- b. False

Quiz: Noise 7

8. Using a narrow measurement bandwidth will _____.
- Improve accuracy and increase the test time.
 - Degrade accuracy and decrease the test time.
9. (T/F) The averaging feature on a spectrum analyzer will improve the accuracy of noise measurements.
- True
 - False

Input Offset Voltage (V_{OS}) & Input Bias Current (I_B)

Multiple Choice Quiz: Solutions

TI Precision Labs – Op Amps



TEXAS INSTRUMENTS

Quiz: Noise 7

1. (T/F) A 10x scope probe is better than a 1x scope probe for noise measurements.

- a. True
- b. False

2. (T/F) The bandwidth limiting feature can be used to improve the noise floor.

- a. True
- b. False

3. Which of the following is NOT a recommended procedure for measuring 1/f noise?

- a. Set scope in ac coupling mode
- b. Use a 0.001Hz high pass filter.
- c. Set time scale to 1 sec per division.

4. (T/F) Ac coupling should be used for broadband noise measurements.

- a. True
- b. False

Quiz: Noise 7

5. What advantage does a spectrum analyzer have over an oscilloscope in noise measurements?

- a. Operation of the spectrum analyzer is fast and simple.
- b. The spectrum analyzer is more accurate
- c. The spectrum analyzer makes it easy to see if you have high frequency content at a specific frequency.
- d. The spectrum analyzer can operate to low frequencies.

6. Which is NOT an important precaution for noise measurements?

- a. Use shield cables to connect to the circuit under test.
- b. Use low ESR capacitors for coupling the circuit under test to the test equipment.
- c. Use linear power supplies or batteries.
- d. Test the noise floor of your equipment.

7. (T/F) The maximum frequency that a spectrum analyzer can measure is called its measurement bandwidth.

- a. True
- b. False

Quiz: Noise 7

8. Using a narrow measurement bandwidth will _____.

- a. Improve accuracy and increase the test time.
- b. Degrade accuracy and decrease the test time.

9. (T/F) The averaging feature on a spectrum analyzer will improve the accuracy of noise measurements.

- a. True
- b. False